



Air Filter Cleaning Instructions

Oil NOT Required for Cleaning


How to Clean a PFP Air Filter

- 1** Shake or tap the filter to remove any large particles of dirt/bugs/leaves that might have gotten trapped in the material.
- 2** Fill a bucket with some dish soap (Dawn) and **warm** tap water, then place the filter into the bucket with the cleaning solution and let it soak for 8-10 minutes. Alternatively, fill a spray bottle with 1tsp dishsoap per gallon of **warm** water, and coat the filter sufficiently, letting it soak for 8-10 minutes.
- 3** Rinse the air filter out with **warm** water from the inside of the filter pushing out any dirt. Do not use a pressure cleaner on the filter.
- 4** Once rinsed thoroughly, shake the filter to get as much water out of it then let it dry. Do not use a hair dryer, compressed air or any other kind of heat source to dry the filter.
- 5** Once the filter surface is clean and dry, you can re-install the filter back into the vehicle.



DO NOT OIL THE FILTER - WARRANTY WILL BE VOIDED


For performance applications, it is recommended to clean the filter **every 10,000 miles** to ensure optimum performance. In normal street applications, it is recommended to clean the filter **whenever the filter looks discolored** from dirt.



CLEANABLE/WASHABLE



NON-OIL WETTED



ENHANCED FIBER MEDIA



Precision Filtration Products | Pennsburg, PA
215-679-6645 | 215-679-6648
sales@pfpusa.com | www.pfpusa.com

